



Enjoy your new upholstered furniture!

The manufacturer takes no responsibility for damages or injuries resulting from improper use or incorrect operation. Warranty claims do not apply to mechanism changes or improper use.

www.schillig.com



ARMREST

with function (foldable step-by-step)

Advice for your upholstered furniture
N° 9

– English –



9.17-06-29-D-E--2_Subject to change.

ARMREST

with function (foldable step-by-step)

This brochure contains information enabling the activation of the function.

The endings with function are no seating accommodation.
Load-bearing capacity up to 25 kg.

Before first usage, please note the following instructions.

You're welcome to watch our clip about this function on the internet.

You can find it on our home page www.schillig.com under the respective model number of your upholstered furniture.

The armrests of your delivered upholstered furniture can be optionally equipped with a function (foldable step-by-step). For adjusting it is possible to activate the function in a sitting position or while standing.

When **seated**, please grab the armrest with your hand at the outside (centered) and move it upwards in an arc-shaped movement. ▶ see image n° 1

When **standing**, please grab it with both hands (at the outside and centered) and move it upwards. ▶ see image n° 2 You can hear how the function clicks into place in the individual positions.

Please make sure that the function is in a horizontal position, as otherwise the function could jam. In the highest position, the function unbolts and the armrest reaches its basic position again by slightly pressing downwards. Before adjusting it again, it is possible to activate the mechanism again. To do so, please slightly push on the armrest from above, until you can hear a click.

– English –

