


W.SCHILLIG



Enjoy your new upholstered furniture!

The manufacturer takes no responsibility for damages or injuries resulting from improper use or incorrect operation. Warranty claims do not apply to mechanism changes or improper use.

www.schillig.com

108.2017-06-29-D-E--3 Subject to change.



CASTERS

with lock protection

advice for your upholstered furniture
N° 108

– English –


W.SCHILLIG

– English –

CASTERS

with lock protection



You've chosen correctly!
Ottoman/lounge chaise with lock protection.

You can simply and comfortably reposition and secure the ottoman/lounge chaise over and over again to your every wish due to the installed casters with lock protection.

Please note the instructions on the opposite page before first usage.

Operating instructions.

A locking device is located above two casters on the long side of your ottoman/lounge chaise. The locking device enables you to change and secure the standing position of your ottoman/lounge chaise within the room at anytime. To release the locking device, simply push back the vertical standing rocker lever with your foot.

► **See image n° 1**

In order to convert your new sofa into a beautiful lounging area, slide the long side of your ottoman/lounge chaise up alongside the front of your sofa. Please notice in the illustration that the long side with both casters is facing outward towards you. You can now comfortably lock the casters into place by applying light pressure with your foot onto the overhanging rocker lever. ► **See image n° 2**

By doing the above, you also avoid scratching the covering on the underside of your upholstered furniture.




Image n° 1: releasing the bracket




Image n° 2: locking the bracket

To ensure proper operation, the rocker lever should hook into the bracket. For your own protection we recommend that you only use the ottoman/lounge chaise if the locking device is applied and secure to prevent the element from sliding away. You can then release the locking device again by pushing down on the rocker lever using foot pressure.

► **See image n° 1**

Note: For optical reasons the thumbnail depiction of the upholstered furniture is enlarged about 1,5 cm with a foot height of 15 cm.