



Enjoy your new upholstered furniture!

The manufacturer takes no responsibility for damages or injuries resulting from improper use or incorrect operation. Warranty claims do not apply to mechanism changes or improper use.

www.schillig.com

65.17-06-2.9D-E--3 Subject to change.



HEADREST

fixed and adjustable

Advice for your upholstered furniture
N° 65

– English –



HEADREST

fixed and adjustable

This brochure includes information for using the plug-in headrest. There are openings for your plug-in headrest in the back of the body of your upholstered furniture. Please handle with care by plugging in or by pulling out the headrest to avoid the damaging of the covering of your furniture.

Please note the instructions on the opposite page before first usage.

Operating instructions.

Fixed plug-in headrest:

By pushing the back cushion slightly towards the seat, a plugging in of the headrest will be easier. Thus you can see and feel, where the opening in the back is.

► See image n° 1

Now push the headrest with little pressure from above **straight downwards** to its final position.

► See image n° 2

To put the headrest into another position, please grab it double-handed on the outside and pull it upwards.

The headrest cannot be adjusted to the front or to the back.

► See image n° 3



Adjustable plug-in headrest:

For plugging in and pulling out the headrest, please do it in the same way, like we explained on the **left-hand side**.

To adjust the plug-in headrest, you have to grab it double-handed on the outside. ► See image n° 4

Stage less support: By little pressure to the front or to the back, you can move it into the desired position. ► See image n° 5

Step-by-step support: By slightly pressing to the front the headrest can be locked into the desired position. As soon as the final position is reached the headrest unlocks.



– English –